0/0 Dimension
(See Plan)

PBU Wall Panel →

Fastener #17A
12-14 x 1¼" SD W/Washer
(6) Per Panel

Inside Closure [HW-459]
(Optional)

Base Trim [FL-72]

1½"

¼"

1½"

Fastener #11
¼ x 1¼" Masonry Anchor
@ 3'-0" O.C. (Pre-Drill
Angle)

2 x 4 x 16 Ga. Base Angle

Concrete Floor

0/0 Dimension
(See Plan)

PBU Wall Panel

Fastener #14A
$\frac{1}{8}$" x $\frac{3}{8}$" Pop Rivet SS
AT 5'–0" O.C.

Fastener #17A
12–14 x 1$\frac{1}{4}$" SD W/Washer
(6) Per Panel

Inside Closure [HW–459]
(Optional)

Base Trim [FL–530]

Fastener #11
$\frac{1}{4}$ x 1$\frac{1}{4}$" Masonry Anchor
@ 3'–0" O.C. (Pre–Drill
Angle)

2 x 4 x 16 Ga. Base Angle

Concrete Floor

0/0 Dimension
(See Plan)

PBU Wall Panel

Fastener #14A
$\frac{1}{8}$" x $\frac{3}{8}$" Pop Rivet SS
AT 5'-0" O.C.

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
(6) Per Panel

Inside Closure [HW-459]
(Optional)

Drip Trim [FL-870]

Masonry Wall
(Not By MBCI)

Concrete Anchor
(Not By MBCI)

Base Cee (16 ga. Min.)

PBU Wall Panel

Fastener #17A
12-14 x 1¼" SD W/Washer
(6) Per Panel

3"

Zee Girt

3'-0"

3" | 6" | 6" | 6" | 6" | 6" | 3"

$\frac{3}{4}$"

Fastener #17A
12-14 x 1$\frac{1}{4}$"
SD W/Washer

PBU Fastener Location At Panel Ends

3'-0"

3" | 1'-0" | 1'-0" | 9"

$\frac{3}{4}$"

Fastener #17A
12-14 x 1$\frac{1}{4}$"
SD W/Washer

PBU Fastener Location
At Intermediate Supports

Prevailing Wind

Installation

Fastener #4A
$\frac{1}{4}$-14 x $\frac{7}{8}$" SD W/Washer
At 1'-8" O.C.

Tape Sealant
$\frac{1}{2}$" x $\frac{3}{32}$" [HW-507]
(Optional)

PBU Panel Sidelap

PBU Wall Panel

Fastener #14A
$\frac{1}{8}$" x $\frac{3}{8}$" Pop Rivet SS
At 5'-0" O.C.

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
(6) Per Panel

Cold Form Header

$\frac{1}{4}$"

Fastener #14A $\frac{1}{8}$" x $\frac{3}{8}$"
Pop Rivet SS At
1'-8" O.C. Each Side
(When Cap Trim Is Used)

Head Trim [FL-852]

Head Cap Trim (FL-37)
(8" Header Only)

PBU Wall Panel

Fastener #14A
$\frac{1}{8}$" x $\frac{3}{8}$" Pop Rivet SS
At 5'-0" O.C.

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
(6) Per Panel

$\frac{1}{4}$"

$\frac{3}{4}$"

Head Trim [FL-852]

Zee Girt

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
At 1'-0" O.C.

Walk Door Angle

Walk Door Header

O/O Dimension
(See Plan)

PBU Wall Panel

Zee Girt

PBU Inside Corner
Trim [FL-815]

Fastener #4A
$\frac{1}{4}$-14 x $\frac{7}{8}$" SD W/Washer
At 1'-8" O.C.

O/O Dimension
(See Plan)

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
(See Fastener Spacing Detail)

Zee Girt

Cold Form Jamb

Fastener #14A $\frac{1}{8}$" x $\frac{3}{8}$"
Pop Rivet SS At
1'-8" O.C. Each Side
(When Cap Trim Is Used)

Jamb Cap Trim (FL-37)
(8" Jamb Only)

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
At 2'-0" O.C.

Jamb Trim [FL-21]

Field Cut As Req'd.

PBU Wall Panel

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
(See Fastener Spacing Detail)

Zee Girt

Fastener #17A
12-14 x 1¼" SD W/Washer
At Each Girt

Walk Door Jamb

Fastener #17A
12-14 x 1¼" SD W/Washer
At 2'-0" O.C.

Jamb Trim [FL-21]

Field Cut As Req'd.

PBU Wall Panel

Fastener #17A
12-14 x 1¼" SD W/Washer
(See Fastener Spacing Detail)

Zee Girt

Cold Form Jamb

Window Or Louver

Fastener #17A
12-14 x 1¼" SD W/Washer
At 2'-0" O.C.

PBU Wall Panel

Fastener #17A
12-14 x 1¼" SD W/Washer
(See Fastener Spacing Detail)

Field Cut Panel As Req'd.

Perimeter Sealant
(Not By MBCI)

Jamb Trim [FL-21]

Fastener #17A
12–14 x 1¼" SD W/Washer
(See Fastener Spacing Detail)

PBU Wall Panel

Wall Girt

Sheeting Angle As Req'd.

O/O Dimension
(See Plan)

PBU Wall Panel
(Field Cut As Req'd.)

Fastener #4A
¼–14 x ⅞"
SD W/Washer
At 1'–8" O.C.

PBU Outside Corner
Trim [FL–845]

O/O Dimension
(See Plan)

Sill Trim (FL-848)

Fastener #14A
$\frac{1}{8}$" x $\frac{3}{8}$" Pop Rivet
At 2'-0" O.C.

Sill Cap Trim (FL-37)
(8" Sill Only)

Fastener #4A
$\frac{1}{4}$-14 x $\frac{7}{8}$" SD W/Washer
At 1'-0" O.C.

Fastener #14A $\frac{1}{8}$" x $\frac{3}{8}$"
Pop Rivet SS At
1'-8" O.C. Each Side
(When Cap Trim Is Used)

Fastener #17A
12-14 x 1$\frac{1}{4}$" SD W/Washer
(6) Per Panel

Cold Form Sill

PBU Wall Panel